

# **INSTRUCTION MANUAL**

## **Patio Heater Light**



**Any questions? Contact us at [www.eventservicesgroup.co.uk](http://www.eventservicesgroup.co.uk)  
Telephone: 03333 442062**

# MOUNTING AND OPERATING INSTRUCTIONS


We are delighted that you have purchased this QUALITY HEATER-LIGHT. **THIS PRODUCT MUST ONLY BE USED UNDER AN UMBRELLA/PARASOL OR USING THE HEATMASTER U3CM CEILING MOUNT IN A GAZEBO OR OTHER COVERED LOCATION.**

For best results and your safety, please follow the instructions carefully. DO NOT modify this product in any way as the manufacturer will accept no liability for improper use.


## MOUNTING THE UNIT

(Follow diagrams below)


1. Ensure parasol is secure and stable by using a suitable parasol base.
2. Remove the vertical thumbscrew as shown.



3. Open unit and attach around the parasol pole. Re-insert vertical thumbscrew and tighten fully home (do not overtighten).




4. Slide unit up the parasol pole to the desired height (no less than 1.8m) and tighten large horizontal clamping thumbscrew.



5. Bring 10m mains lead through hole in table, wind around parasol pole and connect into base of unit.

6. Connect plug on mains lead into an RCD protected outdoor weatherproof socket.




## POSITIONING THE UNIT

1. When choosing a mounting position, it is important to ensure the heater lights are NOT pointed towards combustible surfaces. To adjust, loosen the wing nuts on the side, set the heater-light to desired position and re-tighten. Take care not to pinch the cable between the back of the fittings and the plate. **DO NOT ADJUST WHEN HOT!**
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Children should be supervised to ensure they do not play with the appliance.
4. Heater must be installed at least 1.8m above the floor.
5. Only fit hardened tempered grill in this unit. Any other type of grill could melt and cause damage to the unit or set on fire.
6. Do not use this appliance again if the cable was destroyed.
7. Unit must not be modified in any way.
8. Do not use the heater if the power cord is damaged in any way – contact Heatmaster for a replacement.

## REPLACING THE BULB

1. Unplug the unit.
2. Loosen the screw at the top of the unit and hinge the front open. Release the bulb from the spring loaded lampholders. Insert new bulb into lampholders ensuring it is mounted within 4 degrees of horizontal along its length. It is important that the end-caps on the lamp are making good contact with the lampholders.



Take care not to handle the bulb surface. Should the bulb be accidentally handled during installation, it should be thoroughly cleaned with methylated spirit and a lint free cloth. Close the front and tighten the screw.

*Spare parts are available from your supplier.*

**WARNING: DO NOT TOUCH THE UNIT BEFORE IT COOLS DOWN**

**Any questions? Contact us at  
www.eventservicesgroup.co.uk Telephone: 03333 442062**