

7ft Patio Heater Lighting Instructions

This LPG device is designed for use in well ventilated areas. If you use this heater inside a marquee, tipi, or gazebo you must have 1m clearance from flammable or manmade material.

These instructions are to assist you in lighting your hired gas patio heaters – if you do not feel confident in portering the heater from the delivery point to the point of use, please contact our office and ask for Install & De-Rig to be added to your hire ticket. Each heater can take between 10 – 20 minutes to connect the mushroom top on, connect the gas bottle, purge the gas through ready for use. De-rig is also 10 – 20 minutes. Due to other timed delivery and collection commitments your delivery driver requires advanced notice and authorisation from our office if installation is required.

If your proforma invoice has LPG Pay As You Go - Charge Post Event per kg you will be charged for every kilo used at the Unit Price highlighted in the Unit Price column.

1. The gas control knob and the gas valve it's attached to is fragile – for best results, be gentle.
2. Connect the gas regulator to the gas bottle by screwing the thumb wheel anti-clockwise
3. Tighten finger and thumb tight making sure the black rubber sealing doughnut makes a good seal. It should not be necessary to use any grips or pliers
4. Turn on the valve on the gas supply cylinder 1 – 2 turns ant-clockwise – **not 3 or 4 turns**
5. Lightly turn the variable control knob to **PILOT** position – **do not force the knob**
6. Press gently the variable control knob to allow the gas to purge through the gas pipe to the pilot. **Purging can take between 1 - 2 minutes, if you smell or hear gas, the heater is ready to light.**
7. After 1 minute of pressing the variable control knob, press the piezo igniter button 5 times until the pilot flame lights. If the Pilot flame has not lit, purge the gas through of another 30 seconds and repeat that process until lit.
8. After the Pilot flame has lit, count to 10 and release the variable control knob. If the pilot flame goes out, light the heater again making sure the control knob is pushed fully in.
9. Press lightly and turn the variable control knob to HI (maximum) position and leave it there for about one minute, then turn the variable control knob switch to the desired temperature position.

Tow minute shut off period is necessary before re-lighting, disconnecting or changing a gas bottle.

To Turn off the Heater

- A. Gently turn the variable control knob to **OFF** position.
- B. Then press lightly and turn off the variable control knob to the **OFF** position
- C. Turn the valve on the gas cylinder clockwise to shut down the heater completely.

7ft Patio Heater Lighting Instructions

Purge gas position

Variable control knob

High Temperature

Piezo igniter

