

PATIO HEATER INSTRUCTION



Stainless Steel Bullet Heater

WARNING in RED Text Below

.....
FIRE OR EXPLOSION MAY RESULT IF THESE INSTRUCTIONS ARE IGNORED

- It is the hirer's responsibility to check the patio heater is correctly, installed, taken care of, and not moved with the gas canisters inside or connected.

PRECAUTIONS

- Screw **Propane** regulator **anti-clockwise** finger thumb tight, the rubber doughnut makes a gas tight seal.
- Clip on regulator = **Patio Gas, Leisure gas** or **Gaslight** only
- Leak Test all connections after each connection.
- Never check for leaks with a match or open fire
- Do not store or use gasoline or other flammable substances in the vicinity of this or any other appliance.
- Any LP cylinder not connected for use should not be stored in the vicinity of this or any other appliance.

**** FOR YOUR SAFETY IF YOU SMELL GAS****

1. Turn off the gas supply at cylinder.
2. Extinguish all flames.
3. Do not operate any electrical appliances.
4. Ventilate the area.
5. Check for leaks as detailed in this manual.
6. If odour persists, contact your dealer or gas supplier immediately.

**** Terms & Conditions of On Site & Extended Hires ****

If you are providing your own gas, repairs for blocked pilot jets are chargeable.

For further information please contact 03333 44 2062

FOR OUTDOOR USE ONLY – USE LPG ONLY

Patio Heaters that are supplied on PAYG (pay as you go) basis will have the fuel used charged post event from the Deferred Security Deposit

Switch off gas canister after use, screw the gas valve on canister clockwise – double check gas valve is off before disconnecting the gas regulator.

Patio heaters moved with gas bottles inside, and or still connect to gas will be charged the repair cost of bent panels, and the replacement of the gas regulator and a gas hose.