

Half Oil Drum BBQ

Simple Instructions – Please keep for future reference



Please ensure you empty spent charcoal and ash from the BBQ to avoid charcoal and ash waste disposal charge of £15.00 per BBQ

1. Do not use indoors. Always stand your BBQ outdoors and on level ground away from trees and wooden fencing.
2. **CAUTION** ! Do not use spirit, petrol, paraffin, methylated, lighter fuel or alcohol for lighting or re-lighting.
Use a specially formulated BBQ lighting fluid, paste or fire lighters.
3. Do not attempt to light the fire if lighting fluid has been spilt over clothing.
4. Do not try to re-light the fire with lighting fluid as the charcoal may still be hot and cause a flare-up.
5. **WARNING** ! Keep children and pets at a safe distance from the BBQ area.
6. **ATTENTION!** Do not attempt to move the BBQ once it has been lit.
7. **CAUTION** ! During use always use protective gloves when handling or touching any part of the BBQ.
8. Make sure that the BBQ has completely cooled before removing the ash.
9. Flare-ups can occur if hot fat drips onto the burning charcoal. Keep a water sprayer handy to extinguish the flame.