

Electronic Kitchen Scales



Any questions? Contact us at www.eventservicesgroup.co.uk
Telephone: 03333 442062

1. Position the appliance on a flat, stable surface.
2. Adjust the feet of the appliance to make it level, use a spirit level if necessary.



Note: It is important that the scales are level to ensure accuracy.

Operation



Press to turn ON.

Press whilst On to Tare (set the scales to zero).



Press to turn OFF.



Press to alternate between Metric (kilograms) and Imperial (pounds) readings.



Cleaning, Care & Maintenance

- Clean the weighing tray in warm, soapy water.
- Dry thoroughly after washing.
- Do not immerse the scales in water.
- Remove the batteries (if fitted) if using the adaptor or if the scales are to be left unused for an extended period of time.
- Always unplug the adaptor when not in use to prevent over heating.