

lincat

SEAL

INSTALLATION AND USER INSTRUCTIONS

PIE CABINETS

LPW AND LPW/LR MODELS

SAFETY INSTRUCTIONS



WARNING!

Basic safety precautions, including the following, should be followed to reduce the risk of personal injury. Make sure you have read all of these instructions before switching on the unit.

Keep this User Guide in a safe place for future reference for you and your staff.

Do not clean the unit with a water jet.

REMOVAL OF PACKAGING

In the interest of hygiene, you should clean the product after unpacking and ensure all plastic coatings are removed before use.

Slide the doors to the middle position, lift up and out of the runners to remove. Fit the shelves. Fitting the doors is the reverse of the above sequence.



The unit relies on the circulation of warm air, which must pass through and around the shelves. Ensure circulation is not obstructed by food product or aluminium foil.

GENERAL

Do not try to modify this product.

Ensure that the electrical supply cable is not damaged.

If the supply cable is damaged, it should be replaced by Lincat Ltd or suitably qualified persons, in order to avoid a hazard.

EQUIPOTENTIALITY



This equipment is provided with an equipotential bonding terminal to allow earth cross-bonding with other equipment.

INSTALLATION



Ensure the unit is installed on a sound, level work surface. The unit's external surfaces and base will become hot. You should inform your personnel and customers accordingly.



For safety regulations, the plug must always be accessible.

CONNECTING TO THE ELECTRICITY SUPPLY




Ensure that the voltage of your electricity supply corresponds to the serial plate details. The product is supplied with a 13 Amp plug. To replace the plug, follow these instructions:

- green and yellow wire to 'E' or (Earth)
- blue wire to 'N' (Neutral)
- brown wire to 'L' (Live)




THIS APPLIANCE MUST BE EARTHED.

OPERATING INSTRUCTIONS



LPW Control Panel



LPW/LR Control Panel

1. Cable
2. On/Off Switch
3. Temperature Controller
4. Crumb Tray
5. Light Switch
6. Water Bath

Ensure the shelves are secure. Close doors. To check operation of the unit, connect it to the electricity supply, switch on the On/Off switch (2). The unit has a manual temperature controller (3). Turn on the temperature controller and wait about 15 minutes before loading with pre-heated food. Adjust the temperature to the desired setting.


HUMIDITY FEATURE AND LIGHT (LPW/LR model only)

The integral water bath with lid (6) is intended to keep certain food products moist, such as pastry. For best results, fill with warm water. To prevent condensation on the glass, ensure you do not over-load with food. Check the water level occasionally.

Switch on the light using the green switch. (5).



This part of the unit will become hot. Take care when removing or filling the water bath.



1. Crumb Tray
2. Water Bath
3. Lid