

Spoonshine GP5/GP8 Glass Polisher Instructions.

- Switch machine on at least 10 minutes prior to usage.
- Remove your tray of glasses from the dishwasher, and allow to drain momentarily to remove excess water, OR:
- Hold the glass over steaming water for a few seconds to moisten the glass before polishing.
- Offer glasses to the brushes whilst moist but not soaking wet.
- Move the glasses amongst the brushes ensuring all surfaces come into contact for polishing.
- At the end of the polishing session, leave the brushes to run for at least 15 minutes so as to completely dry them ready for the next session.
- Replace the brushes cover so as to avoid brush contamination from grease particles in the environment.

Spoonshine GP5/GP8 Glass Polisher Operation

The glass polishing system from Spoonshine is designed to speed up the operation involved in polishing glasses to an acceptable standard for the discerning customer.

The appliance uses a mixture of convected warm air, and unique polishing brushes, the warm air is designed to maintain the dryness of the brushes, whilst the brushes themselves do the polishing and drying of the glasses.

The brushes are manufactured to different shapes so that all manner of stemware and even hi ball glasses may be polished. The central brush is for champagne flutes and the surrounding ones are for all other stemware.

If you have any problems with operation. Please call our helpline on: **01626 833120**



Precision Hygiene Ltd
Tel: 01626 833120
Info@spoonshine.co.uk