

INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 1 of 13

INSTRUCTIONS

NACHO WARMER

MODELS:

1995 / 1995S

SAFETY INSTRUCTIONS
TECHNICAL DATA

INSTALLATION INSTRUCTIONS

OPERATION INSTRUCTIONS

MAINTENANCE INSTRUCTIONS

EXPLODED VIEW / PARTS LIST

FAULT DIAGNOSTICS

WIRING DIAGRAM

WARRANTY INFORMATION

DISPOSAL INFORMATION

Customer Information

MODEL NUMBER: _____
SERIAL NUMBER: _____
PURCHASE DATE: _____
DISTRIBUTOR: _____

INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 2 of 13

SAFETY INSTRUCTIONS

IMPORTANT: PLEASE READ INSTRUCTIONS FULLY BEFORE USE

These appliances have been designed to warm nachos prior to serving and therefore during its use parts of the appliance will become hot. All personnel must be given sufficient supervision and training in the safe use of this appliance.

ALL APPLIANCES OTHER THAN THOSE FITTED WITH A SEALED MOULDED PLUG MUST BE FITTED BY A QUALIFIED ELECTRICIAN, IN ACCORDANCE WITH CURRENT REGULATIONS.

The unit should be installed in compliance with the INSTALLATION INSTRUCTIONS and the NATIONAL REGULATIONS in force at the time. Particular attention should be paid to the Health and Safety at Work Act.

To prevent shocks, all appliances whether gas or electric, must be earthed.

To avoid scratching the highly polished exterior surface of this equipment whilst in transit, the protective film on the exterior surfaces has NOT been removed.

It is IMPORTANT that this protective film is peeled off before the equipment is used.

ENSURE THE APPLIANCE IS ISOLATED FROM THE POWER SUPPLY BEFORE INSTALLING, CLEANING OR MAINTAINING THE APPLIANCE

These products have been designed, constructed and marketed in compliance with safety requirements of :

EEC Directive “Low voltage” 73/23;
EEC Directive 93/68.

This product is suitable for contact with foodstuffs, and complies with **EEC Directive 89/109.**

The product(s) stated above are designed and built to comply with the following standards:
BS EN 60335-1

INSTRUCTION REF: IN121
 ISSUE No. 3
 DATE 17.08.15
 Page 3 of 13

TECHNICAL DATA

	1995	1995S
Nominal Voltage:	240 V ~ 50 Hz	
Nominal Current:	0.3	
Nominal Wattage:	70w	
Dimensions W x D x H (mm):	400 x 409 x 505	285 x 297 x 505

INSTALLATION INSTRUCTIONS

ELECTRICAL INSTALLATION

ALL APPLIANCES OTHER THAN THOSE FITTED WITH A SEALED MOULDED PLUG MUST BE FITTED BY A QUALIFIED ELECTRICIAN, IN ACCORDANCE WITH CURRENT REGULATIONS.

OPERATING INSTRUCTIONS

- Your nacho warmer is designed to hold nacho chips at the perfect condition prior to sale. Before loading the warmer must be at the correct holding temperature. To achieve this, switch on the unit with the red switch below the door flap. The switch will illuminate and the display lamp will come on to confirm the unit is powered.
- The unit should now be left for at least 15 minutes to warm up.
- Your nacho warmer can now be loaded with product, this can be done by removing the top and pouring in the chips.

It should be noted that this unit is only suitable for the warming of nacho/tortilla type chips and is not suitable for any other product.

- The unit can be turned off at the red switch when not required.

INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 4 of 13

CLEANING AND MAINTENANCE

ENSURE THE APPLIANCE IS ISOLATED FROM THE POWER SUPPLY BEFORE INSTALLING, CLEANING OR MAINTAINING THE APPLIANCE

Ensure that the appliance has cooled sufficiently.

Cleaning should be carried every day. Clean the external surfaces of the appliance with a damp cloth. Avoid using abrasive materials.

CAUTION: Never clean the appliance with water jets.

Appliance should be annually P.A.T (Portable Appliance Testing) tested for continued electrical safety.

MAINTENANCE INSTRUCTIONS

Servicing


This appliance should be routinely serviced to prolong its lifetime. Parry recommends that the appliance is serviced every 12 months by a Parry authorised engineer. Failure to service your product within the initial 12 month warranty period will cause the 24 month warranty to become void.

MAINTENANCE AND SERVICE MUST ONLY BE UNDERTAKEN BY A QUALIFIED ELECTRICIAN / ENGINEER

IF THE SUPPLY CORD BECOMES DAMAGED, IT MUST BE REPLACED BY THE MANUFACTURER, ITS SERVICE AGENT OR SIMILARLY QUALIFIED PERSONS IN ORDER TO AVOID A HAZARD

INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 5 of 13

EXPLODED VIEW



INSTRUCTION REF: IN121
 ISSUE No. 3
 DATE 17.08.15
 Page 6 of 13

PARTS LIST

ID	Description	1995	1995S
1	*Door	1995DOOR	1995SDOOR
2	Door Knob	KNBK11680	KNBK11680
3	Pin	PINDOMEM3	PINDOMEM3
4	Rear Glass	PLGL00285	PLGL00210
5	Side Glass	PLGL00380	PLGL00270
6	40w Lamp	LPRD00040	LPRD00040
7	Lamp Holder	LPHDES006	LPHDES006
8	*Lid	1995LID	1995SLID
9	Lamp Channel	*No Code	*No Code
10	Front Glass	PLGL00367	PLGL00257
11	Mains Lead	MAINSLEAD	MAINSLEAD
12	Strain Relief Bush	BUSR06003	BUSR06003
13	Terminal Bracket	TERMBRKT1	TERMBRKT1
14	Pad Element	NACHOMATL	NACHOMATS
15	*Element Support Bracket	*No Code	*No Code
16	*Base		
17	Rubber Self Adhesive Foot	RUBBRFOOT	RUBBRFOOT
18	Round Switch <i>(Rectangle switch prior 20th May 2014)</i>	SWRE00008 <i>(SWRE06165)</i>	SWRE00008 <i>(SWRE06165)</i>
19	Round Switch Cover <i>(Rectangle switch cover prior 20th May 2014)</i>	SWRE00008C <i>(LE25COVER)</i>	SWRE00008C <i>(LE25COVER)</i>


INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 7 of 13

FAULTS

The most common fault is that the unit is not connected with the mains supply and so the mains light does not come on.

Try another appliance in the socket, check the socket is turned on, check the wiring to and in the plug, and the plug fuse. One of these may cure your fault. If this is not the case, and for any other problems, first contact your distributor.

IMPORTANT NOTICE




Disconnect the appliance from the mains supply before removing the base.

Any spares or replacements must conform to the relevant standards and the Health and Safety at Work Act and only be fitted by a qualified electrician or competent person.


INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 8 of 13

WIRING DIAGRAM

1995 / 1995S Round Switch



1995 / 1995S Rectangular Switch



(Prior 20th May 2014)

INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 9 of 13

WARRANTY INFORMATION

Warranty Policy

- The manufacturer's warranty is only valid in the UK mainland. Northern Ireland, Western Isles, Inner Hebrides and Islands are parts only warranty.
- All service calls will be carried out between the hours of 8.00am – 5.00pm Monday to Friday only.
- We accept no responsibility for delays in replacing or repairing the equipment due to circumstances beyond our control.
- Your warranty can be immediately invalid if the installation of the equipment has not been carried out in accordance with the manufacturer's instructions. (See installation details). Also the misuse, alteration or unauthorised repairs of the equipment will invalidate the warranty.
- During the warranty period it is at Parry's discretion to repair or replace the equipment.
- Warranty only applies if the equipment has been used in a professional manner following the manufacturer's instructions and maintenance guide lines.
- The warranty covers defects in the material and component failure only. We are not liable for trading loss, loss of perishable items, water damage, loss due to injury or fire damage.
- Please be aware that the warranty starts from the date of purchase from Parry and not the sale or installation date of the equipment.

INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 10 of 13

Warranty Request

- Please ensure you have referred to the manufacturers' instructions before placing a warranty call. Or contact our warranty department on 01757 213909 for technical assistance, ensure you obtain the model number before calling.
- Please ensure you have read the section not covered under warranty to avoid any unnecessary warranty charges.
- It is vital that all warranty requests be submitted to Parry via email to warranty@parry.co.uk
- It is at the discretion of PARRY whether to honour a service call which is out of the warranty period.

Not Covered Under Warranty

- Fault due to poor maintenance.
- Resetting of equipment or circuit breakers.
- Abuse of the equipment
- Foil should never be used on racks
- Blockages e.g., drains, condensers, pumps etc.
- Lime scale related issues
- Installed incorrectly
- Access arranged for service call and engineer refused access or customer not there.
- No faults with the machine.

INSTRUCTION REF: IN121

ISSUE No. 3

DATE 17.08.15

Page 11 of 13

- Setting up of equipment e.g., dishwasher detergents, levelling and setting up of doors on a 6 burner cooker.
- Excessive carbon build up on griddle plates.
- Over use of lava rock on the chargrills. Parry recommends maximum of 2kg.
- Faulty electrics – e.g., customers plug socket, plug, wiring, junction box fault, wrong fuse.
- Any damages caused by the customer.
- Lamps, glass, door gaskets, Perspex, baskets, knobs all perishable items are not covered.


This appliance should be routinely serviced to prolong its lifetime. Parry recommends that the appliance is serviced every 12 months by a Parry authorised engineer. Failure to service your product within the initial 12 month warranty period will cause the 24 month warranty to become void.

INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 12 of 13

Disposal Information

This appliance is marked according to the European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE).

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health which could otherwise be caused by inappropriate waste handling of this product.



A symbol on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it should be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

Disposal must be carried out in accordance with local environmental regulations for waste disposal.

For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Parry Catering recognises our obligations to the EU DIRECTIVE covering the waste disposal of electrical and electronic equipment (WEEE) Parry Catering are committed to this policy in order to help conserve the environment.

INSTRUCTION REF: IN121
ISSUE No. 3
DATE 17.08.15
Page 13 of 13

At the end of this units life you **MUST** dispose of it in an approved manner. You **MUST** not discard the unit or place it in the refuse bin.

You have several options:

- a) Take the unit to an approved WEEE scheme company, there will be one in your area.
- b) Take the unit to an approved waste disposal site; many sites are managed by your local authority.

Contact the units manufacturer, importer or their agent; the contact details will be on the unit.

There will probably be a charge for this service which will depend on the physical size and location of the unit. You will be given a collection price for a curb side collection based on commercial rates prevailing at the time.

It should be noted that the unit to be collected should be suitably packed and sealed to prevent dangerous gases and fluids from escaping. The condition of the unit must also be clean to comply with health and safety regulations.